



Surfboard Shelf

PARTS INCLUDED:

- A. (1) Surfboard shelf
- B. (2) Metal Bracket
- C. (2) Assembly Screws (5/8"L)
- D. (4) Toggle Anchors
- E. (4) Toggle Screws (Flat-tipped 2.25"L)
- F. (4) Stud Screws (1.5"L)
- G. (1) Fin

TOOLS REQUIRED (NOT INCLUDING)

- Phillips head screwdriver
- Level
- Tape
- Pencil

ASSEMBLY (Figure #1):

1. Attach Brackets (B) to shelf by inserting the Assembly Screws (C) through the hole in each bracket and into the pre-drilled marks on underside of shelf.
2. Insert the Fin (G) into the hole at the end of shelf; slide the fin towards the end of the board until the screws are positioned at the narrow slot.

MOUNTING INSTRUCTIONS: Two people are required for mounting.

3. Hold the product (A) at the desired location. NOTE: Use a level to ensure the shelf is not tilting. Using a pencil, mark on the wall through the two pre-drilled holes on each mounting bracket. These marks are the insertion points for the mounting hardware. Gently put the shelf aside on a flat surface.

Drywall Mounting (Figure #2):

3. Use a Phillips screwdriver to install the Toggle anchor(s) (D). Do not use a drill to install the toggle anchors and do not force or "pound" the anchors into the wall. The toggle anchors are designed to cleanly cut and bore themselves into the wall like a drill bit.
4. Position a toggle anchor over one of your insertion point marks. Slowly turn the anchor clockwise while applying even pressure until the flange just touches the wall. If the anchor position is close to a stud (1/2" or less), keep turning clockwise until one of the arrows on the flange is pointing to the 12 o'clock position. Repeat with the other toggle anchors and insertion point marks.
5. Hold the shelf against the wall and align the holes in the brackets to the drywall toggle anchors in the wall. Using a Phillips head screwdriver, insert a Toggle screw (E) through the bracket's pre-drilled holes and into the toggle anchor turning clockwise. At this point, you will feel a slight resistance. This is the point where the toggle anchor screw is engaging the pivoting portion of the anchor. Continue turning the screw clockwise until the screw head touches the shelf's bracket. Continue to tighten the toggle anchor screw until it becomes difficult to turn. At this point the internal pivot will have engaged the backside of the drywall. Repeat with the other toggle screws and anchors.

Stud Mounting (Figure #3)

6. Simply hold the shelf against the wall and align the pre-drilled holes in the brackets to the insertion point marks you made on the wall.
7. Secure the brackets to the wall by installing the Stud Screws (F) through the brackets' pre-drilled holes and into the wall studs at insertion point marks on your wall. Do not over tighten.

CARE INSTRUCTIONS:

- Wipe with a soft, dry cloth.
- Avoid cleaners and abrasives as they may damage the finish.

