



## LM ORNATE CARVE WALL DÉCOR S3 Mounting Instructions

**Note:** For safe mounting, it is important to use the proper hardware for your wall type (drywall, concrete, etc.). Contact your local hardware store for assistance if necessary. For safety and ease of mounting, installation is recommended using two people.

### Tools required for installation:

Phillips screwdriver  
Pencil

### Hardware Included:

(6) Metal Screw  
(6) Anchors

### Wood Stud Mounting:

- 1) Mark the location on the wall.
- 2) Using a Phillips-head screwdriver, drive the screws into the wall at the location. The screws should not be flush to the wall. Leave a gap of about 1/8" between the head of screw and the wall.
- 3) Hang the LM ORNATE CARVE WALL DÉCOR S3 on the screw heads. If it does not fit properly, you may need to adjust the gap between the head of screw and the wall and hang again.

### Dry Wall Mounting:

- 1) Mark the location on the wall.
- 2) Using a Phillips-head screwdriver, drive the dry wall anchors directly into the wall at the location. Do not force the dry wall anchors as they are designed to bore a hole into the wall without much pressure.
- 3) Using a Phillips-head screwdriver, drive the screws into the dry wall anchors. The screws should not be flush to the wall. Leave a gap of 1/8" between the head of screw and the wall.
- 4) Hang the LM ORNATE CARVE WALL DÉCOR S3 on the screw heads. If it does not fit properly, you may need to adjust the gap between the head of screw and the wall, and hang again.



Front view



Back View

### Care and Instructions:

- Wipe with soft, dry cloth.
- To protect the finish, do not apply household cleaners or abrasives.

Thank you for your purchase  
Stores / Catalog / [www.pbteen.com](http://www.pbteen.com)