

PB
teen

Flower String Lights

SKU NO. 4938242 / 4971177


These instructions are for your safety. Please read through them thoroughly before use and retain for future reference.

THIS IS NOT A TOY: KEEP OUT OF REACH OF CHILDREN AND PETS. NEVER TOUCH ITEMS WITH WET HANDS.

Parts Included:

This Flower String Light has (10) Ten non-replaceable LED Light Bulbs.

Battery Box for (3) Three AA batteries (1.5V, type LR6, not included)



IMPORTANT SAFETY INSTRUCTIONS

- 1) READ AND FOLLOW ALL SAFETY INSTRUCTIONS.
- 2) This seasonal use product is not intended for permanent installation or use.
- 3) This Flower String Light is suitable for INDOOR use only.
- 4) Do not position or place near heaters or any other direct sources of heat.
- 5) Always position wire leads so as not to cause a tripping hazard to the elderly, pets and children.
- 6) **DO NOT** position this Flower String Light where it may become covered by other items e.g. curtains, nets or bedding.
- 7) Read and follow all instructions that are on the product or provided with the product.
- 8) SAVE THESE INSTRUCTIONS

Pre-Assembly:

- Note: This Flower String Light comes fully assembled.
- Remove all parts and hardware from box along with any plastic protective packaging, taking care not to damage or twist the wires while unpacking.
- Check the product before use for loose or damaged wiring and that all the bulbs are secure.
- Do not discard any contents until after set-up is complete to avoid accidentally discarding small parts or hardware.

Battery Installation:

- Open the cover of Battery Box. Remove previously installed (old) batteries and if needed, clean the new battery terminals and also the Battery Box contacts prior to battery installation.
- Install (3) three new AA batteries (1.5V, type LR6, not included), taking care to match the battery direction to the polarity markings displayed inside the battery compartment (+ and -). High quality alkaline batteries are recommended for maximum battery life.
- Close battery cover and secure the cover in place.
- Remove all batteries if product is to be stored or not used for an extended period of time.
- Remove used batteries promptly.
- **Always replace batteries as a simultaneous set.**
- **Do Not Mix Old And New Batteries. Do Not Mix Alkaline, Standard (Carbon - Zinc), Rechargeable Nickel - Cadmium or Rechargeable Nickel Metal Hydride Batteries**

- **CAUTION:** To avoid explosion or leakage, do not dispose of batteries in a fire or attempt to recharge standard or alkaline batteries. Please dispose of batteries safely according to the battery manufacturer's instructions or recycle battery per state and local codes. If battery leakage occurs and comes in contact with the skin or eyes, wash immediately with plenty of water. Batteries should be handled under adult supervision. If the device is not to be used for an extended period of time, remove the batteries to prevent damage or injury from possible battery leakage.

To set the battery box switch to the desired mode:

- "ON" - The Flower String Light will light up.
- "OFF" - The lights will be turned off immediately. Turn off when not in use to save battery life.

If the lights fail to light-up properly, please check the following:

- Open the Battery Box, check the expiration date on the installed batteries.
- Check that the batteries are all correctly positioned within the battery compartment.
- If needed, replace with new batteries as a simultaneous set.
- Check if the battery terminals and Battery Box contacts are clean.
- This product uses long-lasting, non-replaceable LED bulbs.

Use and Care Instructions:

Before using or reusing, inspect product carefully.

Discard any parts that have cut, damaged, or frayed wire insulation or cords, cracks in the lampholder or enclosures, loose connects or exposed copper wire.

When storing the product, carefully remove the product from its location, to avoid any undue strain or stress on the product conductors, connections, and wires.

When not in use, store neatly in a cool, dry location protected from sunlight.

Clean the product with a soft, dry cloth. Do not use solvents or abrasive cleaners as they may damage the finish.

Thank you for your purchase
Stores | Catalog | www.pbteen.com