


CHELSEA SIMPLE DESK

ASSEMBLY INSTRUCTIONS



www.pbteen.com

Important Safety Instructions:

- Please read all instructions carefully before assembling this Desk.
- For your safety, assembly by two or more adults is strongly recommended.
- Keep these instructions for future use.
- Use only vendor-supplied hardware to assemble this item. Using unauthorized hardware could jeopardize the structural integrity of the item.


Pre-assembly:


- Remove all parts and hardware from the box. Place all items on a carpeted or scratch-free work surface, as this will avoid damaging parts during assembly. The shipping box provides an ideal work surface.
- To avoid accidentally discarding small parts or hardware, do not dispose of any packaging or contents of the shipping carton until assembly is complete.
- Use the parts and hardware lists below to identify and separate each of the pieces included.
- The illustrations provided allow for easier assembly when used in conjunction with the assembly instructions.
- The use of power tools to aid in assembly is not recommended. Power tools can damage the hardware and split the wood.

Parts Included:

(A) Table Top (1x)

(B) Legs (4x)





Tools Required (not included):




Philips Head Screwdriver

www.pbteen.com

Assembly Instruction Steps:

- 1. Carefully place Table Top (A) upside down, on a flat, scratch-free surface.
- 2. Attach each of the Table Legs (B) to the Table Top (A), as seen in the illustration below.
- 3. Secure with 8 sets of: Flat Washers (F), Spring Washers (E), and Allen Bolts (D) through the pre-drilled holes on the corner blocks of the Table Top (A) -to the pre-fixed insert nuts on top of the Table Legs (B).
- 4. Tighten with the supplied Allen Key (C).



- 5. Turn the Desk upright.
- 6. Adjust the levelers located on the bottom of each leg (either in or out) to make the desk sit level.



Care Instructions:

- Dust often using a clean, soft, dry, and lint-free cloth.
- Blot spills immediately and wipe with a clean, damp cloth.
- We do not recommend the use of chemical cleansers, abrasives, or furniture polish on our lacquered finish.
- Hardware may loosen over time. Periodically check to make sure all connections are tight.Re-tighten if necessary.

www.pbteen.com